



NOTE:

IF BLOCKING IS MISSING, STAPLE WALL UNDERLAY TO SOFFIT PLATE TO AVOID ANY VENTILATION GAPS

REFER TO E2/AS1 TABLE 1 FOR RISK LEVELS. EAVE FLASHINGS ARE REQUIRED WHEN FASCIA IS 100mm OR LESS FROM WALL CLADDING AND ROOF PITCH IS LESS THAN 10°

SCALE 1:10

STOTHERM SYSTEM	STOTHERM INSULATED FACADE SYSTEM	ST 600
	FLAT SOFFIT/WALL JUNCTION WITH TIMBER FASCIA	2017