



**NOTE:**

IF BLOCKING IS MISSING, STAPLE WALL UNDERLAY TO SOFFIT PLATE TO AVOID ANY VENTILATION GAPS

REFER TO E2/AS1 TABLE 1 FOR RISK LEVELS. EAVE FLASHINGS ARE REQUIRED WHEN FASCIA IS 100mm OR LESS FROM WALL CLADDING AND ROOF PITCH IS LESS THAN 10°

SCALE 1:10

<b>STOTHERM SYSTEM</b>	<b>STOTHERM INSULATED FACADE SYSTEM</b>	<b>ST 611</b>
	<b>FLAT SOFFIT/WALL JUNCTION WITH METAL FASCIA</b>	<b>2017</b>