



METER BOX AT HEAD

- APPLY STOARMAT MIRAL PLASTER SYSTEM WITH STO uPVC DRIP EDGE AT HEAD
- PREPARE REBATES, APPLY TWO (2) COATS OF STOFLEXYL WATERPROOFING BEFORE APPLYING STOARMAT MIRAL SYSTEM. LEAVE 10mm SEALANT JOINT
- MS SEALANT OVER STO JOINT SEAL TAPE TO PERIMETER OF METERBOX
- THICKEN BASECOAT ON REBATES TO ACHIEVE A 6-8mm FINISHING GAP BEFORE SEALING

METER BOX AT SILL

- MS SEALANT OVER STO JOINT SEAL TAPE
- PREPARE REBATES, AND APPLY TWO (2) COATS OF STOFLEXYL WATERPROOFING BEFORE APPLYING STOARMAT MIRAL PLASTER SYSTEM. LEAVE 10mm SEALANT JOINT
- STOARMAT MIRAL PLASTER SYSTEM

SCALE 1:5

STO CONCRETE BLOCK	STO CONCRETE BLOCK	CB 351
	METER BOX	2014

The information contained in this detail is based on our experience and testing and represents the latest information available at the date of issue. This detail is intended for use by the design professional and users of Sto products to assist in developing specific project details to be used in conjunction with a Sto Specification. We reserve the right to alter or update information at any time without prior notice & it is the responsibility of the specifier and/or the project manager to insure that they have the current Sto details and specifications.