



1. SHEET JOINTS MUST NOT COINCIDE WITH JOINERY EDGE UNLESS A CONTROL JOINT IS TO BE FORMED
2. ALL SHEET EDGES SHALL LINE THROUGH AND BE SUPPORTED BY A BATTEN. SHEET JOINTS BETWEEN BATTENS MUST BE SECURELY WIRED TOGETHER
3. LOCATE INTER-STOREY JOINTS AS PER SPECIFICATION
4. ALL SHEET JOINTS TO BE STAGGERED
5. ALL SHEETS TO BE OVERLAPPED AS DETAILED
6. INSTALL 8-12mm STO CONTROL JOINTS @5.400M MAX.CTRS
7. REINFORCE NARROW WIDTHS, STRESS POINTS, DOORS and LARGE WINDOWS

N.T.S

STOSTUCCO SYSTEM	STOSTUCCO CONSTRUCTION SYSTEM	SS 006
	STOSTUCCO S/S LATH SET UP	2014

The information contained in this detail is based on our experience and testing and represents the latest information available at the date of issue. This detail is intended for use by the design professional and users of Sto products to assist in developing specific project details to be used in conjunction with a Sto Specification. We reserve the right to alter or update information at any time without prior notice & it is the responsibility of the specifier and/or the project manager to insure that they have the current Sto details and specifications.