



NOTE:
 LEAVE 40mm DRAINAGE GAP IN SEALANT AT BOTTOM OF FAN COVER.
 INSTALL FLASHING TAPE 100mm AROUND PIPE ONTO WALL UNDERLAY AND WRAP 25mm ROUND PIPE.
 FOR FLEXIBLE PIPES, TAPE PIPE TO FAN COVER, APPLY STO JOINT SEAL, TAPE AROUND TAPE BEFORE PLACING IN HOLE. ALWAYS FINISH PLASTER BEFORE INSTALLING FAN COVER

SCALE 1:2

| | | |
|-------------------------|--------------------------------------|---------------|
| STOSTUCCO SYSTEM | STOSTUCCO CONSTRUCTION SYSTEM | SS 356 |
| | FAN VENT DETAIL | 2014 |