



1. SHEET JOINTS MUST NOT COINCIDE WITH JOINERY JAMB EDGES UNLESS A CONTROL JOINT IS TO BE FORMED
2. ALL SHEET EDGES SHALL LINE THROUGH AND BE SUPPORTED BY A FRAMING MEMBER
3. LOCATE INTER-STOREY JOINTS AS PER BOARD MANUFACTURERS SPECIFICATIONS
4. STAGGER VERTICAL SHEET JOINTS AT INTER-STOREY JUNCTION
5. HORIZONTAL CONTROL JOINTS AT INTER-STOREY JUNCTIONS
  - 8mm VERTICAL CONTROL JOINTS AT 5.400M CTRS.MAX
  - INTER-STOREY DRAINED JOINTS EVERY THIRD FLOOR

N.T.S

<b>STO/ MONOTEK</b>	<b>STOARMAT RENDER SYSTEM</b>	<b>FCS 008</b>
	<b>SHEET and SYSTEM LAYOUT</b>	<b>2017</b>