



THIS METHOD IS USED TO INSTALL FULL HEIGHT SHEETS WHERE THE WALL HEIGHT IS TALLER THAN THE STANDARD SHEET HEIGHT. THIS METHOD MUST NOT BE USED AT FLOOR JOISTS OR GABLE ENDS AS A CONTROL JOINT.

SCALE 1:2

<b>STO/ MONOTEK</b>	<b>STOARMAT RENDER SYSTEM HORIZONTAL SHEET JOINT</b>	<b>FCS 301</b>
		<b>2017</b>