



STOARMAT RENDER SYSTEM

1. PROVIDE 6mm MIN. FILLET BEAD OF MS SEALANT TO JAMBS & SILL
2. BUILDER TO INSTALL FLASHING TAPE TO CORNERS & SILL OVER WALL UNDERLAY
3. POSITION WINDOW OFF BOARD BY 2-3mm TO ALLOW FOR STOARMAT JAMB & SILL FLASHINGS

WARNING: SOME BRANDS OF ALUMINIUM JOINERY HAVE DRAINAGE VENTS IN THE BOTTOM EDGE OF THE SILL FLANGE. ENSURE DRAINAGE VENTS REMAIN CLEAR.

SCALE 1:2

STO/ MONOTEK	STOARMAT RENDER SYSTEM	FCS 401
	ALUMINIUM JOINERY - SILL DETAIL	2017