



NOTE:

IF BLOCKING IS MISSING, STAPLE WALL UNDERLAY TO SOFFIT PLATE TO AVOID ANY VENTILATION GAPS

REFER TO E2/AS1 TABLE 1 FOR RISK LEVELS. EAVE FLASHING REQUIRED WHEN FASCIA IS 100mm OR LESS FROM WALL CLADDING AND ROOF SLOPE IS LESS THAN 10° OR WIND ZONES ARE VERY HIGH OR EXTRA HIGH

SCALE 1:10

STO/ MONOTEK	STOARMAT RENDER SYSTEM	FCS 600
	FLAT SOFFIT/WALL JUNCTION	2017