



1. INSTALL METAL SADDLE FLASHING AT WALL JUNCTION
2. ENSURE TOP IS TEMPORARILY WATERPROOFED BEFORE PLASTERING
3. METAL CAPPING EXCLUDING DRIP EDGE MUST OVERLAP SHEET BY
50mm MIN.IN LOW, MED or HIGH WIND ZONE,
70mm MIN.IN VERY HIGH,
90mm MIN.IN EXTRA HIGH WIND ZONES
4. INSTALL METAL CAPPING TO ALL ROOF PARAPETS

SCALE 1:5

**STO/
MONOTEK**

**STOARMAT CONSTRUCTION SYSTEM
PARAPET/METAL FLASHING DETAIL**

MFCS 500

2014