



NOTE: APPLY STOFLEXYL MESHED WATERPROOFING OVER STOPOREN MESHED BASECOAT RENDER.

STO FLEXYL MESHED WATERPROOFING HAS BEEN TESTED BY BRANZ TO MEET AS/NZS4858 FOR A WATERPROOFING MEMBRANE AS REQUIRED BY E2/AS1

A. NZBC - E2/AS1 REQUIRES BALCONY & PARAPET WALLS TO BE OFFSET FROM THE MAIN WALL PLANE TO ALLOW FOR SADDLE FLASHINGS

SCALE 1:10

STOPOREN FACADE	STOPOREN FACADE (40mm cavity) SYSTEM	PP 1024
	STOFLEXYL MESHED SADDLE FLASHING	2018