



**NOTE:** INSTALL FLASHING TAPE OVER BRACKET ONTO BUILDING UNDERLAY AS PER E2/AS1 fig 68, ALSO REFER TO DETAIL 510

MANUFACTURED GALVANIZED STEEL 'H' OR 'U' BRACKET FOR PARALLEL JOISTS OR USE 'L' BRACKET FOR RIGHT ANGLE CONNECTIONS

INSTALL DECK JOIST AFTER CLADDING IS RENDER FINISHED  
40mm GAP RECOMMENDED FOR FIXINGS AND RENDERING

SCALE 1:5

<b>STOPOREN FACADE</b>	<b>STOPOREN FACADE SYSTEM</b>	<b>PP 512</b>
	<b>PARALLEL DECK JOIST BRACKET</b>	<b>2018</b>