



1. WINDOW CONTRACTOR TO INSTALL WINDOW WITH 5mm GAP. STO JOINT SEAL TAPE TO BACK EDGE OF ALU.FLANGE ON THE HEAD & JAMBS AS REQUIRED FOR SPECIFIC DESIGN AND THEN MS SEALANT TO HEAD & JAMBS
2. BRUSH APPLY STO FLEXYL / MESH FROM REBATE OUT OVER EPS BLOCK
3. BUILDER TO INSTALL PERIMETER AIR SEAL

WARNING

SOME BRANDS OF ALUMINUM JOINERY HAVE DRAINAGE VENTS IN THE BOTTOM EDGE OF THE SILL FLANGE. ENSURE DRAINAGE VENTS REMAIN CLEAR

SCALE 1:5

<p>STO EPS-B SYSTEM</p>	<p align="center">STO EPS/ICF BLOCK ALUMINIUM JOINERY JAMB DETAIL</p>	<p align="center">EB 401</p>
		<p align="center">2014</p>