



NOTE:
INSTALL STOFLEXYL UNDER DPM AT TRANSITION IF REQUIRED FOR POORLY DRAINED SITES.

SCALE 1:5

STOPOREN FACADE	STOPOREN FACADE SYSTEM	PP 205
	EPS BLOCK FOUNDATION DETAIL	2020