



1. FLASHING TAPE SYSTEM TO BE INSTALLED AROUND JOINERY OPENINGS AS PER E2/AS1 DETAILS.
2. THE ALUMINIUM WINDOW HEAD FLASHING BUTTS INTO THE STO CAVITY JAMB TO PROVIDE STOPEND AFTER REMOVING THE JAMB TAB AND FITTING TO JOINERY BEFORE FITTING WINDOW HEAD FLASHING TIGHT AND MS SEALANT THE JUNCTIONS - SEE *DETAIL PP402*
3. IN EXTRA HIGH WIND ZONES INCREASE FLASHING COVER TO 60mm MIN. AND USE A RIGID UNDERLAY

SCALE 1:2

<b>STOPOREN FACADE</b>	<b>STOPOREN FACADE SYSTEM</b>	<b>PP 401</b>
	<b>ALU.JOINERY - HEAD DETAIL - CAVITY JAMB</b>	<b>2020</b>