



NOTE:

INSTALL FLASHING TAPE OVER BRACKET ONTO BUILDING UNDERLAY AS PER E2/AS1 fig 68, ALSO REFER TO DETAIL 510 MANUFACTURED GALVANISED STEEL 'H' OR 'U' BRACKET FOR PARALLEL JOISTS OR USE 'L' BRACKET FOR RIGHT ANGEL CONNECTIONS. INSTALL DECK JOIST AFTER CLADDING IS RENDER FINISHED 40mm GAP RECOMMENDED FOR FIXINGS AND RENDERING

SCALE 1:2

STOPOREN FACADE	STOPOREN FACADE SYSTEM	PP 512
	PARALLEL DECK JOIST BRACKET	2020