



1. HEIGHT WORK TO UNDERSIDE SOFFIT. MEASURE DOOR HEIGHT ON SITE & CHECK GARAGE DOOR SPECIFICATIONS FOR INTERNAL CORNER REQUIREMENTS
2. SEAL FLASHING FOR VERY HIGH or EXTRA HIGH WIND ZONES
3. IN EXTRA HIGH WIND ZONES INCREASE FLASHING COVER TO 60mm AND USE A RIGID AIR BARRIER

SCALE 1:2

STO/CONCRETE BLOCK	STOVENEER WOOD SYSTEM	VWCB 416
	GARAGE DOOR - TIMBER HEAD	2020

The information contained on this page is based on our experience and research at the date of issue. The detail is for use by Registered Architects, Licensed Designers or Chartered Engineers to assist in developing project details using Sto Systems. Stoanz Ltd reserve the right to alter or update information at any time without prior notice and it is the responsibility of the designer, project manager or Sto contractor to insure they have and use the current Sto details and specifications on site.