



1. HEIGHT WORK TO UNDERSIDE SOFFIT. MEASURE DOOR HEIGHT ON SITE & CHECK GARAGE DOOR SPECIFICATIONS FOR INTERNAL CORNER REQUIREMENTS
2. SEAL FLASHING FOR VERY HIGH or EXTRA HIGH WIND ZONES
3. IN EXTRA HIGH WIND ZONES INCREASE FLASHING COVER TO 60mm AND USE A RIGID AIR BARRIER

SCALE 1:2

STO/ MONOTEK	STO VENEER WOOD SYSTEM	VWFC 416
	GARAGE DOOR - TIMBER HEAD	2021