



1. HEIGHT WORK TO UNDERSIDE SOFFIT. MEASURE DOOR HEIGHT ON SITE AND CHECK GARAGE DOOR SPECIFICATIONS FOR INTERNAL CORNER REQUIREMENTS\
2. SEAL FLASHING FOR VERY HIGH or EXTRA HIGH WIND ZONES
3. IN EXTRA HIGH WIND ZONES INCREASE FLASHING COVER TO 60mm MIN.AND USE A RIGID UNDERLAY

SCALE 1:2

STO POREN PANEL	STOVENEER WOOD SYSTEM	VWPP 409
	GARAGE DOOR - TIMBER HEAD	2020