



1. FLASHING TAPE SYSTEM TO BE INSTALLED AROUND JOINERY OPENINGS AS PER E2/AS1 DETAILS
2. STO UPVC CAVITY VENTED HEAD FLASHING CAN BE USED WHERE A RENDERED HEAD IS DETAILED - REFER *DWG PP 401*
3. IN EXTRA HIGH WIND ZONES INCREASE FLASHING COVER TO 60mm MIN. AND USE A RIGID UNDERLAY
4. 10mm MINIMUM HEAD FLASHING OR PROPRIETARY STOP ENDS REQUIRED

SCALE 1:2

<b>STOTHERM SYSTEM</b>	<b>STOTHERM INSULATED FACADE SYSTEM</b>	<b>ST 400</b>
	<b>ALU.JOINERY - HEAD DETAIL - STICK ON JAMB</b>	<b>2017</b>

The information contained on this page is based on our experience and research at the date of issue. The detail is for use by Registered Architects, Licensed Designers or Chartered Engineers to assist in developing project details using Sto Systems. Stoanz Ltd reserve the right to alter or update information at any time without prior notice and it is the responsibility of the designer, project manager or Sto contractor to insure they have and use the current Sto details and specifications on site.