



1. FLASHING TAPE SYSTEM TO BE INSTALLED AROUND JOINERY OPENINGS AS PER E2/AS1 DETAILS.
2. THE ALUMINUM WINDOW HEAD FLASHING BUTTS INTO THE STO CAVITY JAMB TO PROVIDE STOPEND AFTER REMOVING THE JAMB TAB AND FITTING TO JOINERY BEFORE FITTING WINDOW HEAD FLASHING TIGHT AND MS SEALANT THE JUNCTIONS - SEE *DETAIL PP402*
3. IN EXTRA HIGH WIND ZONES INCREASE FLASHING COVER TO 60mm MIN. AND USE A RIGID UNDERLAY

SCALE 1:2

STOTHERM SYSTEM	STOTHERM INSULATED FACADE SYSTEM	ST 401
	ALU.JOINERY - HEAD DETAIL - CAVITY JAMB	2017

The information contained on this page is based on our experience and research at the date of issue. The detail is for use by Registered Architects, Licensed Designers or Chartered Engineers to assist in developing project details using Sto Systems. Stoanz Ltd reserve the right to alter or update information at any time without prior notice and it is the responsibility of the designer, project manager or Sto contractor to insure they have and use the current Sto details and specifications on site.