



1. FLASHING TAPE SYSTEM TO BE INSTALLED AROUND JOINERY OPENINGS AS PER E2/AS1 DETAILS
2. STO UPVC CAVITY VENTED HEAD FLASHING CAN BE USED WHERE A PLASTERED HEAD IS DETAILED - REFER DWG PP 401
3. IN EXTRA HIGH WIND ZONES INCREASE FLASHING COVER TO 60mm MIN. AND USE A RIGID UNDERLAY
4. 10mm MINIMUM HEAD FLASHING OR PROPRIETARY STOP ENDS REQUIRED

SCALE 1:2

<b>STO POREN FACADE</b>	<b>STO POREN FACADE SYSTEM</b>	<b>PP 400</b>
	<b>ALU.JOINERY - HEAD DETAIL - STICK ON JAMB</b>	<b>2017</b>