



NOTE:
 JOINERY SUPPORT BAR REQUIRED ON OPENINGS OVER 600mm.
 SEALANT IS APPLIED TO THE SILL AND JAMBS
 WINDOW HEADS ARE LEFT OPEN
 FLEXIBLE FLASHING TAPE SYSTEM TO BE INSTALLED AROUND
 JOINERY OPENINGS AS PER E2/AS1 DETAILS

WARNING:
 SOME BRANDS OF ALUMINIUM JOINERY HAVE DRAINAGE VENTS IN THE
 BOTTOM EDGE OF THE SILL FLANGE. ENSURE DRAINAGE VENTS REMAIN CLEAR.

SCALE 1:2

STO POREN PANEL	STOVENEER WOOD SYSTEM	VWPP 401
	ALUMINIUM JOINERY - SILL DETAIL	2020