


NOTE: 600mm FRAMING
 FIXINGS AT 300mm CENTRES GENERALLY ON FRAMING 150mm FROM PANEL EDGE WITH ONE FIXING BETWEEN STUDS ON THE BOTTOM PLATE ON FRAMING @ 600mm CTRS max.
 REFER TO FOUNDATION DETAILS FOR SPECIFIC FIXING LAYOUT

SCALE 1:20

STOPOREN FACADE	STOPOREN FACADE SYSTEM	PP 100
	CAVITY BATTEN SETOUT (600ctrs) - ISOMETRIC	2020

The information contained on this page is based on our experience and research at the date of issue. The detail is for use by Registered Architects, Licensed Designers or Chartered Engineers to assist in developing project details using Sto Systems. Stoanz Ltd reserve the right to alter or update information at any time without prior notice and it is the responsibility of the designer, project manager or Sto contractor to insure they have and use the current Sto details and specifications on site.




NOTE: 400mm FRAMING
 FIXINGS AT 300mm CENTRES GENERALLY ON STUDS 150mm FROM PANEL EDGE AND 400mm CTRS ALONG BOTTOM PLATE ON FRAMING @ 400mm CTRS max.
 REFER TO FOUNDATION DETAILS FOR SPECIFIC FIXING LAYOUT

SCALE 1:20

STOPOREN FACADE	STOPOREN FACADE SYSTEM	PP 101
	CAVITY BATTEN SETOUT (400ctrs) - ISOMETRIC	2020

The information contained on this page is based on our experience and research at the date of issue. The detail is for use by Registered Architects, Licensed Designers or Chartered Engineers to assist in developing project details using Sto Systems. Stoanz Ltd reserve the right to alter or update information at any time without prior notice and it is the responsibility of the designer, project manager or Sto contractor to insure they have and use the current Sto details and specifications on site.

STEEL FRAME CONSTRUCTION MUST BE SPECIFIC DESIGN MEETING REQUIREMENTS OF NZBC.
 FOR STEEL FRAMED BUILDINGS SITUATED IN NZS 3604 WIND ZONES UP TO VERY HIGH STUDS ARE AT 600mm MAX.CTRS. FOR ALL OTHER DWELLINGS STUDS ARE AT 400mm MAX.CTRS, DWANGS ARE REQUIRED AT 800mm CTRS
 PROVIDE THERMAL BREAK TO ALL STEEL MEMBERS **OR** BRANZ APPRAISED PROPRIETARY RIGID AIR BARRIER/THERMAL BREAK





NOTE: 600mm FRAMING
 FIXINGS AT 300mm CENTRES ON FRAMING 150mm FROM PANEL EDGE WITH ONE FIXING BETWEEN STUDS ON THE BOTTOM PLATE OVER FRAMING @ 600mm CTRS max.
 REFER TO FOUNDATION DETAILS FOR SPECIFIC FIXING LAYOUT

SCALE 1:20

STOPOREN FACADE	STOPOREN FACADE SYSTEM	PP 102
	CAVITY BATTEN SETOUT STEEL FRAME/THERMAL BREAK (600CTRS)	2020

The information contained on this page is based on our experience and research at the date of issue. The detail is for use by Registered Architects, Licensed Designers or Chartered Engineers to assist in developing project details using Sto Systems. Stoanz Ltd reserve the right to alter or update information at any time without prior notice and it is the responsibility of the designer, project manager or Sto contractor to insure they have and use the current Sto details and specifications on site.



NOTE: EXTRA CAVITY BATTEN OR STRAPPING TAPE REQUIRED BETWEEN STUDS FOR FLEXIBLE UNDERLAY CONSTRUCTION on 600 FRAMING

N.T.S

STOPOREN FACADE	STOPOREN FACADE SYSTEM	PP 103
	CAVITY BATTEN LAYOUT (400 & 600ctrs) ELEVATION	2020

The information contained on this page is based on our experience and research at the date of issue. The detail is for use by Registered Architects, Licensed Designers or Chartered Engineers to assist in developing project details using Sto Systems. Stoanz Ltd reserve the right to alter or update information at any time without prior notice and it is the responsibility of the designer, project manager or Sto contractor to insure they have and use the current Sto details and specifications on site.