



NOTE: USE FULL PANELS WHERE POSSIBLE.
 ALL PANEL CUTS SHALL BE CAREFULLY MADE TO ACHIEVE A TIGHT BUTT FIT.
 ALL PANEL JOINTS MUST BE BONDED WITH POREN ADHESIVE MORTAR OR AAC 2 HOUR CONSTRUCTION GLUE.
 MECHANICALLY FIX ALL PANELS WITH POREN SCREW FIXINGS AT MAXIMUM 300mm CENTRES.
 PRIME ANY EXPOSED STEEL REINFORCING ENDS AND BUTT JOIN WHERE POSSIBLE.
 PANELS TO BE SUPPORTED BY MINIMUM TWO STUDS OR BLOCKING.
 VERTICAL CONTROL JOINTS REQUIRED AT MAXIMUM 8m CENTERS, REFER STO DETAILS.
 HORIZONTAL CONTROL JOINTS AT INTERSTOREY JUNCTION IF UNSEASONED JOISTS USED.
 HORIZONTAL DRAINED JUNCTION REQUIRED AT THIRD STOREY OR 7 METERS

N.T.S

STO POREN FACADE	STO POREN FACADE SYSTEM	PP 300
	PANEL LAYOUT	2020

The information contained on this page is based on our experience and research at the date of issue. The detail is for use by Registered Architects, Licensed Designers or Chartered Engineers to assist in developing project details using Sto Systems. Stoanz Ltd reserve the right to alter or update information at any time without prior notice and it is the responsibility of the designer, project manager or Sto contractor to insure they have and use the current Sto details and specifications on site.