



**NOTE:**  
 INSTALL STOFLEXYL UNDER DPM AT TRANSITION IF REQUIRED FOR POORLY DRAINED SITES.  
 STRUCTURAL LAYOUT IS INDICATIVE ONLY AND SUBJECT TO INDIVIDUAL PROJECT DESIGN

SCALE 1:5

<b>STO POREN SYSTEM</b>	<b>STOVENEER WOOD SYSTEM</b>	<b>VWPP 203</b>
	<b>EPS BLOCK FOUNDATION DETAIL</b>	<b>2020</b>

The information contained in this detail is based on our experience and testing and represents the latest information available at the date of issue. This detail is intended for use by the design professional and users of Sto products to assist in developing specific project details to be used in conjunction with a Sto Specification. We reserve the right to alter or update information at any time without prior notice & it is the responsibility of the specifier and/or the project manager to insure that they have the current Sto details and specifications.